

OWNER'S MANUAL

MOTORIZED TREADMILL



PLEASE READ THE INSTRUCTIONS CAREFULLY BEFORE
ASSEMBLY AND USING THE TREADMILL
KEEP THE MANUAL FOR FUTURE REFERENCE.

WARNING

- When using this treadmill, keep attaching the safety key rope to your clothes.
- When you are running, keep your hands swinging naturally, your eyes staring forward and never look down at your feet.
- Increase the speed step by step when running.
- When emergency happens, take away the "safety key" immediately.
- Leave the treadmill after the running belt is fully stopped.

Caution: Read the assembly instruction carefully, follow the instruction when assemble.

ATTENTION

- 01- Before starting any exercise program, consult with your physician or health professional.
- 02- Check all the bolts are securely locked.
- 03- Never put the treadmill in a humid area, or it will cause troubles.
- 04- We take no responsibility for any troubles or hurts due to above reasons.
- 05- Dress sport clothes and shoes before running.
- 06- Do not do exercise in 40 minutes after meal.
- 07- To prevent hurts, please warm up before exercise.
- 08- Consult with doctor before exercise if you have high blood pressure.
- 09- The treadmill is only used for adults.
- 10- Do not plug anything into any parts of this equipment, or it may be damaged.
- 11- Do not connect line to the middle of cable; do not lengthen cable or change the cable plug; do not put anything heavy on cable or put the cable near heat source; forbid using socket with several holes, these may cause fire or people may be hurt by the power.
- 12- Switch off the power when the equipment is not used. When the power is cut off, do not pull the power line to keep the wire unbroken.
- 14. Maximum weight of user 180KGS.
- 15. Pulse data may not be very accurate, so cannot be used for medical purpose. Over-exercise may cause injury, even death. If you have a feeling of dizziness, sickness or other abnormal symptoms, please stop training and consult a doctor immediately.

IMPORTANT SAFETY PRECAUTIONS

1. Plug the power cord of the treadmill directly into a dedicated grounded circuit. This product must be grounded. If it has breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock.
2. Position the treadmill on a clear, level surface. Do not place the treadmill on thick carpet as it may interfere with proper ventilation. Do not place the treadmill near water or outdoors.
3. Position treadmill so that the wall plug is visible and accessible.
4. Never start the treadmill while you are standing on the walking belt. After turning the power on and adjusting the speed control, there may be a pause before the walking belt begins to move, always stand on the foot rails on the sides of the frame until the belt is moving.
5. Wear appropriate clothing when exercising on the treadmill. Do not wear long, loose fitting clothing that may be caught in the treadmill. Always wear running or aerobic shoes with rubber soles.
6. Make sure the power supply is connected and the safety key is effective before using the treadmill. Fit one side of the safety key on the treadmill and clip the other side on your clothes or belt, which will enable you to pull off the safety lock promptly in an emergency.
7. Always unplug the power cord before removing the treadmill motor cover.
8. Make sure there is no less than 2*1m space behind the treadmill.
9. Keep children away from the treadmill during operation.
10. Always hold the handrails when initially walking or running on the treadmill, until you are comfortable with the use of the treadmill.
10. Always attach the safety key rope to your clothing when using the treadmill. If the treadmill should suddenly increase in speed due to an electronics failure or the speed being inadvertently increased, the treadmill will come to a sudden stop when the safety key is disengaged from the console.
12. In case of any abnormality during the use process, please remove the safety key immediately, grasping the handlebar and jumping onto the two edgings, then get off the treadmill after it stops.
13. When the treadmill is not being used, the power cord should be unplugged and the safety key removed.
14. Put the safety key away where it cannot be reached by the children.
15. Before starting any exercise program, consult with your physician or health professional. He or she can help establish the exercise frequency, intensity (target heart zone) and time appropriate for your particular age and condition. If you have any pain or tightness in your chest, an irregular heartbeat, shortness of breath, feel faint or have any discomfort while you exercise, STOP! Consult your physician before continuing.
16. If you observe any damage or wear on the mains plug or on any section of the mains lead then please have them replaced immediately by a qualified electrician – do not attempt to change or repair these yourself.


17. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

18. Put your feet on the side rail before using the treadmill, and always attach the safety key rope to your clothing. Hold the handle bar before the running belt moving well (feel the running speed by your single foot before using it). To avoid losing balance, please slow down the speed to the lowest or take off the safety lock. And hold the handle bar to jump to the side rails when emergency or the safety key is not attached.

ASSEMBLY STEPS


STEP 1:

1. Open the packing box, take out the above materials from the box, and lay the main frame on the ground.




STEP 2:

1. Connect the computer lower wire (86) and computer connecting wire (85)
2. Lock the upright tube (2L/R) on the main frame (1) with inner hexagonal head bolts (46), internal serrated locking washer (72), don't lock the inner hexagonal head bolts (46) now.




STEP 3:

1. Insert the upright tube cover (29L/R) into the upright tube (2L/R);
2. Connect the computer upper wire (84) and computer connecting wire (85);
3. lock the computer frame(3) on the upright tube(2L/R) with the inner hexagonal head bolts (46)、 internal serrated locking washer(72);
4. Lock the all bolts tightly;
5. lock the upright tube cover(29L/R) on the computer lower cover(24) with cross recessed pan self tapping screw(62).




STEP 4:

1. As picture 1 shown, connect the wires of panel bracket (4) and computer frame (3) (Lines of the same number are joined together);
2. lock the panel bracket(4)on the computer frame(3)with inner hexagonal head bolts(48)、 standard spring washer(79)and standard plain washer(75);
3. attach the computer panel connecting cover(32)to the computer panel lower cover(30)by using cross recessed pan head self tapping screw(62).




STEP 5:

1.fasten the frame side tube cover(20L/R)on each end of the main frame(1)and adjust the right hole site, and then lock them with cross grooved washer head screw(54)、cross recessed self tapping screw with padded head(61)and cross recessed pan head self tapping screw(62).



STEP 6:

- 1.install the motor cover(18)on the main frame(1),adjust the right hole site, and then lock it tightly by using cross grooved washer head screw(55);
2. Insert the end of power line (90) into the power socket of main frame (1).



GROUNDING METHODS

This product must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock.

This product is equipped with a cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.


DANGER – Improper connection of the equipment-grounding conductor can result in a risk of electric shock. Check with a qualified electrician or serviceman if you are in doubt as to whether the product is properly grounded.

Do not modify the plug provided with the product – if it will not fit the outlet; have a proper outlet installed by a qualified electrician.

This product is for use on a nominal **220-volt** circuit and has a grounding plug that is accordance with VDE. Make that the product is connected to an outlet having the same configuration as the plug. No adaptor should be used with this product.

Please pay great attention to the voltage of power and the plug of the power. Wrong voltage and plug will cause fault of the product. Below plug just for setting reference.



Grounding Methods



TECHNICAL PARAMETER



ASSEMBLY SIZE (mm)	2210*990*1580	POWER	AS ORDER
RUNNING SURFACE (mm)	600X1630	INPUTVOLTAGE	220 V
NET WEIGHT	260KG	SPEED RANGE	1.0-25 KM/H
GROSS WEIGHT	360KG	INCLINE	0-15 level

OPERATION INSTRUCTIONS


















1. Window display


















1. : display speed;
2. : display time;
3. : display distance;
4. : display incline;
5. : display calories and steps, when it lit, display calories; when it lit, display steps;
6. : display program and heart rate, when it lit, display the name of program; when it lit, display heart rate;

7.  indicator light: when it lit, the system is refueling automatically;
8.  indicator light (optional): when it lit, the system is connected to bluetooth
9. The indicator lights of handrail and rear cap: Used to indicate the running state of the treadmill, when the light is green, the treadmill is standby mode; when the treadmill is running state, the light is red

2. Button instruction

1. **Function button** : , , , , , , , , , , , , , , , , , , PAUSE.

2. Function button instruction :

- A  START: Press this button to start treadmill
- B PAUSE: Press this button to stop treadmill (Press one time to pause, twice to stop)
- C  PROGRAM: when the treadmill on standby, select program P01-P18, user-defined U-1 to U-3 and FAT
- D  MODE: In standby state, press the key to select different countdown mode, time, distance, calorie; When setting user-defined programs, it is used to switch different segments so that the speed and incline of each segment can be set.
- E SPEED:   add and subtract the speed: Adjust the speed
- F SPEED SHORTCUT KEY: , ,  when motor is working, the key moves the speed to the speed value marked on the key.
- G INCLINE:   incline add-subtract key: adjust the incline
- H INCLINE SHORTCUT KEY: , ,  when motor is working, the key moves the incline to the incline value marked on the key.
- I Volume add-subtract key: ,  adjust the volume when playing music
- J Previous/next key: ,  select playlist to play music

3. Functions of the safety key

When motor is working, remove the safety lock to stop the motor and can't start.

4. Heart rate function

When the treadmill is power-connected, grip the left and right armrests with both hands to receive the

accurate heart rate. Please stand on the treadmill and test it after the machine is stop, and the time no less than 30 seconds .Display range: 50-200 times/ min.

This data is for reference only and cannot be used as medical data.

5. Range of values

	initial	Set initial value	setting range	indication range
Time(minute: second)	0:00	30:00	5:00-99:00	0:00-99:59
Speed	0.0	1.0	1.0-25.0KM/H	1.0-25.0KM/H
Incline	0	0	0-15	0-15
Distance	0.0	1.00	1.00 - 99.0	0.0 - 99.9
Calories	0	50.0	20.0 - 990.0	0 - 999.9

6. PROGRAM

Program P01-P18


time program	Setup time/16 =each segment of the running time																
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	
P1	speed	2	3	3	4	5	3	4	5	5	3	6	8	7	6	5	2
	incline	0	1	2	2	2	3	3	2	2	3	3	3	2	2	2	0
P2	speed	2	3	5	7	9	10	7	5	6	8	10	12	7	6	5	2
	incline	0	1	2	3	4	5	5	5	5	5	5	5	4	3	2	0
P3	speed	2	5	8	9	10	10	10	10	10	10	8	9	7	8	5	2
	incline	0	1	2	4	6	5	5	5	4	4	8	8	5	2	2	0
P4	speed	2	3	6	9	10	12	8	9	7	6	6	7	12	10	5	2
	incline	0	1	2	5	7	8	8	8	8	8	8	8	6	4	2	0
P5	speed	2	6	12	8	10	12	12	12	12	12	8	9	7	6	5	2
	incline	0	2	4	5	5	5	5	3	5	2	5	5	5	2	2	0
P6	speed	2	4	6	8	10	12	8	10	10	12	8	12	10	6	4	2
	incline	0	3	2	2	5	5	5	2	2	4	5	3	2	2	2	0
P7	speed	2	6	9	10	10	10	10	9	8	7	6	6	8	6	5	2
	incline	0	3	5	5	5	7	9	10	9	7	3	3	2	2	2	0
P8	speed	2	5	8	9	5	9	5	9	5	9	6	9	7	9	5	2
	incline	0	1	3	3	3	5	7	9	13	14	14	14	6	4	2	0
P9	speed	2	3	6	9	11	8	13	8	13	8	13	8	13	8	5	2
	incline	0	1	5	7	7	3	3	2	2	4	3	3	2	2	2	0
P10	speed	2	6	8	14	15	13	14	9	8	13	6	9	7	6	5	2
	incline	0	2	2	2	2	3	3	3	3	3	5	5	5	5	2	0
P11	speed	2	3	4	5	6	7	8	9	10	11	12	9	7	6	5	2
	incline	0	3	4	5	6	6	6	6	6	6	8	8	8	5	2	0
P12	speed	2	6	7	9	11	13	14	8	8	9	7	9	7	6	5	2












	incline	0	1	2	3	4	5	6	7	8	9	10	11	8	6	2	0
P13	speed	2	6	8	11	12	13	15	13	15	13	15	13	11	7	5	2
	incline	0	4	5	5	5	3	3	2	2	4	6	4	3	2	2	0
P14	speed	2	5	8	12	15	11	14	15	15	13	9	8	8	6	5	2
	incline	0	3	2	2	5	3	3	5	2	4	8	8	7	5	2	0
P15	speed	2	6	10	14	11	13	8	10	15	13	9	9	7	6	5	2
	incline	0	2	4	6	8	8	8	8	8	8	5	5	3	4	2	0
P16	speed	2	8	9	9	10	13	9	10	8	9	13	9	7	6	5	2
	incline	0	3	2	2	4	3	3	2	2	4	3	3	3	2	2	0
P17	speed	2	7	9	10	15	13	12	11	10	9	8	7	7	6	5	2
	incline	0	2	2	5	5	3	3	3	3	4	3	6	2	4	2	0
P18	speed	2	5	8	10	9	8	7	8	9	10	16	9	7	6	5	2
	incline	0	4	2	4	4	3	3	5	5	5	5	3	2	2	2	0

7. User program


In addition to 18 built-in programs, the treadmill also has 3 customized programs to support the customized setting based on the user's specific situation: U-1, U-2 and U-3.

1、 Settings of user programs::

In the standby mode, press  key in succession to the user program U-1、 U-2、 U-3, meanwhile

 when it lit, display preset time, press   or 、  setup required exercise time, press  key confirm to enter setup parameters, then you can set the first time period, press 、  key or speed shortcut key to set speed, press   key or incline shortcut key to set incline; Press  key to finish the first time period setting then enter the second time period state until complete the all 16 time period setting, the data will be saved until the next time you reset the data. This data will not be lost due to power failure

2、 User-defined startup:

Select User-defined program, after set then press  key to start it up.

8. HRC Function

HRC1 speed limit (Max-4.0km/h), HRC2 speed limit (max-2.0km/h), HRC3 Max

1.HRC setting: after repeatedly pressing P button to get to HRC, press M to advance to the next setting, adjust speed or inclination accordingly

A: age setting:13-80, default 30

B: target heart rate: (220 minus age)*0.6

C: target heart rate is changeable, ranging from 0.45 to 0.75 (220 minus age)

D: maximum heart rate: (220 minus age)

2. speed

A: change sequence, HRC detects heart rate every 30 sec

B: If the user's heart rate is lower than target heart rate by 30 times/min, then speed increases by 2 km/h

C: if such a discrepancy is within 1-29 times/min, then speed increases by 1 km/h

D: Vice versa, if the user's heart rate is higher than target heart rate, the speed decreases and the same rule applies

E: During the following circumstances, the treadmill will run at 1km/h for 15 sec and then shut down automatically; in the 15 sec, the treadmill will beep for each second elapsed

A: No heart rate detected for more than one minute

B: Heart rate exceeds (220 minus age)

9. Body fat test (FAT)

In the standby state, press **[F]** key continuously to enter body fat test program, the window display "FAT". Press **[M]** key to select the parameter of F1(gender), F2(age), F3(height), F4(weight), press "speed+/-" or **[+]**, **[-]** key can set the parameter. After setting will display F5, hold heart rate to enter body fat test, check to see if your weight matches your height. Body mass index (FAT) it's a measure of a person's height and weight, not body proportions, FAT is fit for any male or female, it provide a basis for people to adjust their weight. The ideal FAT should be between 20-25, If less than 19 means too thin, and if between 25-29 is overweight and if more than 30 is obesity. (The parameter is only for reference, not medical judgment)

F1 gender 1 man 2 woman
F2 age 10-----99
F3 height 100----220
F4 weight 20-----150
F5 FAT ≤19 **Under weight**
 FAT = (20---25) **Normal weight**
 FAT = (25---29) **Over weight**
 FAT ≥30 **Obesity**

10. Power saving mode

In the standby state, if there is no key instruction input in 10 minutes, the system will enter the power saving mode and shutdown the display automatically

11. Shutdown

Turn off the treadmill at any time by turning off the power switch so that it doesn't damage the treadmill

12. Meanings of error message codes

Code	Fault description	Reasons	Solutions
E1	Computer and lower controller communication abnormality	The computer and lower controller wires was not connected well	Check the wires of computer and lower controller
		Computer fault	Replace a computer
		The lower controller fault	Replace a lower controller
E2	Over-heat protection	Temp Sensor short circuit	Replace inverter
		Inverter fault	

		Fan fault	
E3	Low-voltage protection	power voltage below 185V	Make sure the voltage in the right range
		power voltage normal	
E4	Incline motor correction failure or error	Incline motor correction failure	Re-check incline motor after power on
		Inverter connection loosed	Check the connection
		Inverter broken	Change inverter and re-check it
		Incline motor broken	Change the incline motor and re-check
E5	Over-current protection	motor with over current	Lubricating oil to reduce the resistance between running belt and running board
		IPM module short circuit	Replace inverter
E6	Lower controller and inverter communication abnormality	Lower controller and inverter was not connected well	Check the Lower controller and inverter whether connected well
		Lower controller fault	Replace lower controller
		Inverter fault	Replace inverter
E7	Over- load protection	parameter setup error	Replace inverter
		over-loading	reduce loading
E9	Incline signal error	Incline sensor not connect well	Check the connecting of incline sensor
		Incline motor fault	Change incline motor
		Inverter fault	Change inverter


EXERCISE INSTRUCTIONS

1. The Warm Up Phase

This stage helps get the blood flowing around the body and the muscles working properly. It will also reduce the risk of cramp and muscle injury. It is advisable to do a few stretching exercises as shown below. Each stretch should be held for approximately 30 seconds, do not force or jerk your muscles into a stretch - if it hurts, **STOP**.

2. The Exercise Phase

This is the stage where you put the effort in. After regular use, the muscles in your legs will become Stronger. Work to your but it is very important to maintain a steady tempo throughout. The rate of work should be sufficient to raise your heart beat into the target zone shown on the graph below.



This stage should last for a minimum of 12 minutes though most people start at about 15-20 minutes

3. The Cool Down Phase

This stage is to let your Cardio-vascular System and muscles wind down. This is a repeat of the warm up exercise e.g. reduce your tempo, continue for approximately 5 minutes. The stretching exercises should now be repeated, again remembering not to force or jerk your muscles into the stretch.

As you get fitter you may need to train longer and harder. It is advisable to train at least three times a week, and if possible space your workouts evenly throughout the week.

To tone muscle while on your Treadmill you will need to have the resistance set quite high. This will put more strain on our leg muscles and may mean you cannot train for as long as you would like. If you are also trying to improve your fitness you need to alter your training program. You should train as normal during the warm up and cool down phases, but towards the end of the exercise phase you should increase resistance, making your legs work harder than normal. You may have to reduce your speed to keep your heart rate in the target zone.

The important factor here is the amount of effort you put in. The harder and longer you work the more calories you will burn. Effectively this is the same as if you were training to improve your fitness, the difference is the goal.


MAINTENANCE INSTRUCTIONS

WALKING BELT CENTERING AND TENSION ADJUSTMENT


DO NOT OVERTIGHTEN the walking belt. This may cause reduced motor performance and excessive roller wear.

TO CENTER WALKING BELT:

- Place treadmill on a level surface
- Run treadmill at approximately 3.5 mph
- If the belt offs the track to the right side, please screw the right adjusting bolt clockwise slowly, noticing the change of the deviating distance, until center the belt. (Attention: the space between the belt and the right/left edgings is at a distance normally. And the gap between the right and left distance should be no more than 5mm.
- If the belt offs the track to the left side, please screw the left adjusting bolt clockwise slowly, noticing the change of the deviating distance, until center the belt. (Attention: the space between the belt and the right/left edgings is at a distance normally. And the gap between the right and left distance should be no more than 5mm.



Picture A: If the belt has drifted to the RIGHT



Picture B: If the belt has drifted to the LEFT

TENSIONING THE BELT

If you can feel a slipping sensation when running on the treadmill, the running belt must be tightened. In most cases, the belt has stretched from use, causing the belt to slip. This is a normal and common adjustment. To eliminate this slipping, tension both the rear roller bolts with the appropriate size allen wrench, turning it **1/4 TURN** to the right as shown. Try the treadmill again to check for slipping. Repeat if necessary, but **NEVER TURN** the roller bolts more than **1/4 turn** at a time. The belt tension is set properly when the running belt is **50 - 75mm** from the deck.

WARNING: ALWAYS UNPLUG THE TREADMILL FROM THE ELECTRICAL OUTLET BEFORE CLEANING OR SERVICING THE UNIT.

CLEANING

General cleaning of the unit will greatly prolong the treadmill. Keep treadmill clean by dusting regularly.

Be sure to clean the exposed part of the deck on either side of the walking belt and also the side rails.


This reduces the build up of foreign material underneath the walking belt.

The top of the belt may be cleaned with a wet, soapy cloth. Be careful to keep liquid away from inside the motorized treadmill frame or from underneath the belt. **Warning: Always unplug the treadmill from the electrical outlet before removing the motor cover.** At least once a year remove the motor cover and vacuum under the motor cover.

WALKING BELT AUTOMATIC LUBRICATING SYSTEM

- 1) Remove the safety lock and press START and STOP for 2s at the same time to enter refuel parameter setting. The time window will display the refuel time each time. Press INCLINE+/- to adjust the refuel time. The refuel time will be up or down 10s per time. When the distance window display operation KM for each refuel, press SPEED+/- to adjust the distance. The speed will be up or down 10KM per time.
- 2) Every 150 Km, the oil must be added once, refill oil needs 20s.
- 3) When the system shows that the oil depot is closed, will regard that the oil out of use and the dot matrix window display “PLEASE ADD OIL FULL”. This thereof user must turn off power to change oil depot or refill the oil depot. When finish the operation, the system will clear up the “PLEASE ADD OIL FULL” prompt and the product can be used again.

EXPLODED DRAWING



PARTS LIST

Part No.	Description	Qty	Part No.	Description	Qty
1	Main frame	1	51	hexagon socket cap screws M10*55	1
2L/R	Upright tube	1 pr.	52	Cross recessed pan head screw M6*15	2
3	Computer frame	1	53	Cross recessed pan head screw M6*20	4
4	Panel bracket	1	54	Cross grooved washer head screw M5*8	10
5	Incline frame	1	55	Cross grooved washer head screw M5*16	12
6	Running board clamp	2	56	Edging gasket	10
7	Oil tube connecting frame	1	57	Cross grooved washer head screw M4*15	6
8	Ground wire base	1	58	Cross grooved washer head screw M4*8	6
9	Front roller	1	59	Plastic edging mounting	10
10	Hand pulse	4	60	Cross recessed countersunk head screw M3*15	2
11	Rear roller	1	61	Cross recessed self tapping screw with padded head ST4.0*12	17
12	Bearing rack	2	62	Cross recessed pan head self tapping screw ST4.0*12	88
13	Adjustable foot pad	2	63	Cross recessed pan head self tapping screw ST2.9*9.5	2
14	PU wheel	2	64	Scraping end of cross groove pan head self tapping screw ST2.9*6	6
15	Bearing spacer	4	65	Cross recessed pan head self tapping screw ST4*55	4
16L/R	Metal slip sheet	1pr.	66	Cross recessed countersunk head self tapping screw ST4*16	24
17	Bearing	4	67	Chamfer large flat head inner hexagon self tapping self drilling nail ST6*16	16
18	Motor cover	1	68	Nylon nut M10	8
19	Frame side tube front cover	1	69	Nylon nut M6	4
20L/R	Fame side tube cover	1pr.	70	Hexagonal nut M20*2.5	2
21L/R	Edging	1pr.	71	Hexagonal nut M3	2
22	End cover	1	72	Internal serrated locking washer Φ 10*1.2	23
23	Computer upper cover	1	73	Standard plain washer Φ 12*2.5	8
24	Computer lower cover	1	74	Standard plain washer Φ 10*2.0	8
25L/R	PU foam grip	1pr.	75	Standard plain washer Φ 8*1.6	6
26	Stop key	1	76	Standard plain washer Φ 6*1.6	4
27	Safety lock socket	1	77	Standard spring washer Φ 12*3.1	8
28	Safety lock	1	78	Standard spring washer Φ 10*2.1	4
29L/R	Upright tube cover	1pr.	79	Standard spring washer Φ 8*2.1	6

30	Computer panel lower cover	1	80	Standard spring washer $\Phi 6*1.6$	4
31	Computer panel	1	81	Standard spring washer $\Phi 5$	2
32	Computer panel connecting cover	1	82	pinboard	1
33	Silicon cushion	2	83	Short-cut key	2
34	Running board	1	84	Computer upper wire	1
35	Running belt	1	85	Computer connecting wire	1
36	Running board locating part	4	86	Computer lower wire	1
37	Belt	1	87	Ac motor	1
38L/ R	Non-slip mat	1pr.	88	Incline motor	1
39	cushion	2	89	gasoline pump	1
40	Rear end cap upholstery cover	2	90	Power line	1
41	Inner hexagonal head bolts M12*35	8	91	Rocker switch	1
42	Outer hexagon bolt M10*70	2	92	Overload protector	1
43	Outer hexagon bolt M10*55	5	93	Power socket	1
44	Pressure spring	2	94	inverter	1
45	Outer hexagon bolt M8*40	1	95	MP3/earphone interface(Optional)	1
46	Inner hexagonal head bolts M10*20	16	96	Audio cable(Optional)	1
47	Inner hexagonal head bolts M8*15	1	97	Loudspeaker(Optional)	2
48	Inner hexagonal head bolts M8*20	6	98	Inductor(Optional)	1
49	Inner hexagonal head bolts M10*115	1	99	Filter(Optional)	1
50	hexagon socket cap screws M10*75	2	100	USB interface(Optional)	1